



#3 Install ToneStyler, and connect cable & wires to the master volume pot, as shown.